

EasyLight Solar System



NR-VT-LS01
03/2008

free energy europe

Due to ongoing improvement policy, this documentation is subject to modification without prior notice.

EasyLight Solar System

POWER

USE

Solar panel

Light



Install in 1 step and switch on your Light !

1 Plug Solar panel cable into Light.



www.freeenergyeurope.com

EasyLight Solar System

SYSTEM COMPONENTS

NR-VT-LS01

1x free energy europe Solar panel FEE-5-6, 4 Watt peak, 6 Volt

Dimensions 343 mm (L) x 317 mm (W) x 12.5 mm (H), 1.5 kg

Installation four holes for easy installation

Wiring 5 meter double insulated cable (2x 0.75 mm²) with double socket jack attached

Guarantee 10 years product guarantee



1x Soltys LED Light Soltys Elixo Light, 0.5 Watt, 6 Volt

Dimensions 96 mm (D) x 72 mm (H), 210 gr


Installation easy fix to wall or ceiling with cord

Lights 10x bright LED's

Beams wide beam, narrow beam

Modes high intensity (~ 10 hrs use), medium intensity (~ 40 hrs use), flash mode

Batteries 3 batteries: rechargeable, type AA (LR6) Ni-MH 1.2V



You can do more on a day with **free energy europe** solar panels !


Solar panel

Number of Lights that can be powered with specific panel: *


* Based on 5 hours full sun equivalent (5 kWh/m²/day)



5 Watt



7 Watt



14 Watt



www.freeenergyeurope.com

free energy europe

Address: Parc de la Croisette • 2, Rue Léon Droux, B.P. 66 • 62302 Lens Cedex • France

Email: info@freeenergyeurope.com • Website: www.freeenergyeurope.com

Telephone: +33 (0)3 21 79 30 60 • Fax: +33 (0)3 21 43 65 88